


RFID čitač+antena velikog dometa


za automatsko otvaranje rampi, kapija, vrata...

Dva režima rada: I - samostalni i II - sa kontrolerom



1. Antena šalje signal RFID nalepnici:

2. RFID nalepnica šalje ID šifru čitaču:




RFID čitač+antena velikog dometa

za automatsko otvaranje rampi, kapija, vrata...


I - Samostalni režim rada




1. Auto prilazi spuštеноj rampi:




2. Antena šalje signal RFID nalepnici:



3. RFID nalepnica šalje ID šifru čitaču:



4. Rampa se automatski podiže:



RFID čitač+antena velikog dometa

za automatsko otvaranje rampi, kapija, vrata...

II - Režim rada sa kontrolerom kontrole pristupa

